

Tech Manual TQ Series RO Systems



Models:

TQ 172
TQ 172N
TQ 173
TQ 173N
TQ 174
TQ 176

TABLE OF CONTENTS

1.0 General Information

About this Manual	3
The Kinetico TQ Series Product Line.....	4
System Sizing TQ 172 / 173	5
System Sizing TQ 174 / 176	7

2.0 Equipment Specifications

System Configuration	9
System Accessories	10
Operating Specifications	12
Component Functionality TQ 172 / 173	13
Component Functionality TQ 174 / 176	15

3.0 Installation

Getting Started	19
Pre-installation Review	19
TQ System Installation	19
Unpacking	20
System Hook-ups	20

4.0 Operation and Maintenance

Normal Operating Procedures	21
System Commissioning	21
Sanitization of Storage Tank	22
Sanitization of QuickFlo Tank	23
Membrane Sanitization	23
Troubleshooting	24

5.0 Parts27

6.0 System Log31

TQ REVERSE OSMOSIS SERIES

Manual part number: 10152B
© Kinetico Incorporated, August 2004



About this Manual

This manual will cover information needed for the proper installation and operation of your Kinetico TQ Series Commercial Reverse Osmosis System. We have also included information regarding the frequently asked questions about reverse osmosis systems. This information may be more technical in nature, but provides further insight to the continued operation of this equipment to its highest standards.

This manual will use various icons to help highlight issues that are relevant to the safe operation of this equipment. The following icons will be used as described:



General information regarding the application of this product will be highlighted by this icon. This will include technical specifications and expected operational results.



Lock out electrical power.

Use appropriate lockout procedures when servicing.



Maintain safe pressure.

This sign indicates the safe operating pressure range.



Consult Maintenance Section.

Refer to the maintenance section for specific instructions.



Consult Equipment Specifications Section.

Refer to the equipment specifications section for specific instructions.



Consult MSDS Sheets.



A caution icon will be used to present any information that may hold a potential hazard or concern during the installation, use or maintenance of this product. **Should this information not be followed, it may result in damage of this equipment and its surroundings.**



Electrical shock or electrocution hazard.



Pinch point or crushing hazard.



Chemical hazard.



The warning icon will be used to present any information that may result in a severe hazard or concern during the installation, use or maintenance of this product. **Should this information not be followed, it may result in severe physical harm.**



Stay Clear.



Do Not Touch.



No Access.

Only properly trained and authorized persons can enter area or open panel.



Any tools or materials required during the installation, use or maintenance of this equipment will be preceded by this icon. Using these specific tools will minimize time and effort. Not using the proper tool may result in damage to this equipment, its surroundings or even physical harm.

If there are any additional questions pertaining to this equipment, please contact your local Kinetico Dealer for further assistance.

The Kinetico TQ RO Product Line

Kinetico's TQ product line provides both reverse osmosis and nanofiltration products that include electric and non-electric models. The reverse osmosis product line is designed to provide high quality reverse osmosis water using line pressure to operate all system features for the TQ 172 and TQ 173. The TQ 174 and TQ 176 use a pump to boost pressure to the system. Both the electric and non-electric versions are designed to allow the unit to be installed domestically and internationally, regardless of electrical requirements. The electric versions have a universal transformer that only requires a plug change to power the unit. The capacity of Kinetico's TQ RO Series systems accommodates daily production requirements from 150 to 450 gpd. The TQ Nanofiltration line is designed to provide a slightly lower quality permeate water than reverse osmosis. The capacity of Kinetico's TQ Nano Series accommodates daily production requirements from 200 to 300 gpd.

System features for the TQ Series include:

- Corrosion Resistant Aluminum Anodized Bracket
- Low Pressure / Low Temperature Production
- EverClean Rinse®
- Compact System Design
- Reverse Osmosis or Nanofiltration Membrane Choice TQ 172 and TQ 173
- System Features for TQ 172 and TQ 173 (Wall Mount Systems)
 - Non-Electric Operation / Optional booster pump available
 - Wall-mountable, Space Saving Design
 - Choice of RO or Nanofilter membranes
- System Features for TQ 174 and TQ 176 (Cabinet Floor Systems)
 - Integrated Low Voltage Pump
 - Movable, Rolling Caster Design

A number of accessories are also available with the TQ Series systems including:

- Carbon Filters
- Backwashing Filters
- Softeners
- Storage Tanks

For further information regarding these products, please contact your local Kinetico Dealer.

Wall Mount Systems

Model Name	TQ 172	TQ 173	TQ 172n	TQ 173n
Part Numbers				
Reverse Osmosis System	10162	10163	XX	XX
Nanofiltration System	XX	XX	10166	10167
Rated* Daily Production	150 gpd	225 gpd	200 gpd	300 gpd
Rated* Daily Production	568 lpd	852 lpd	757 lpd	1,136 lpd
Membrane Type	Thin Film Composite			
Number of Membranes	2	3	2	3

* Based on feed TDS of 500 mg/l and a water temperature of 77 °F

Floor Mount Systems

Model Name	TQ 174	TQ 176
Part Numbers		
RO System 120v/60 hz (US Plug)	11585	11560
RO System 230v/50hz (European Plug)	11589	11588
Rated* Daily Production	300 gpd	450 gpd
Rated* Daily Production	1,136 lpd	1,704 lpd
Membrane Type	Thin Film Composite	
Number of Membranes	4	6

* Based on feed TDS of 500 mg/l and a water temperature of 77 °F

System Sizing TQ 172 / 173

In the application of the TQ 172 / 173 Series wall mount systems, three important site variables must be taken into account:

- Water Temperature
- Inlet Pressure
- Inlet Water Quality

To determine the output performance of the unit, a compensated inlet pressure must be determined. The inlet pressure is compensated based on the quality of the inlet water. For each 100 TDS, 1 psi is reduced for the actual inlet pressure.

Example:

Actual Inlet Pressure	55 psi
Inlet TDS	1,000 mg/l
TDS Pressure Reduction:	$1,000 \text{ mg/l} / (100 \text{ (mg/l)/psi}) = 10 \text{ psi}$
Compensated Inlet Pressure:	$55 \text{ psi} - 10 \text{ psi} = 45 \text{ psi}$

TQ172

Reverse Osmosis System

Compensated Inlet Pressure

Temperature	40 psi	50 psi	60 psi	70 psi	80 psi
40 °F	33 gpd	46 gpd	55 gpd	66 gpd	71 gpd
45 °F	37 gpd	52 gpd	63 gpd	74 gpd	80 gpd
50 °F	42 gpd	58 gpd	71 gpd	84 gpd	90 gpd
55 °F	48 gpd	66 gpd	80 gpd	95 gpd	102 gpd
60 °F	54 gpd	74 gpd	90 gpd	106 gpd	114 gpd
65 °F	60 gpd	83 gpd	101 gpd	119 gpd	128 gpd
70 °F	67 gpd	93 gpd	113 gpd	133 gpd	144 gpd
75 °F	75 gpd	104 gpd	126 gpd	149 gpd	161 gpd
80 °F	82 gpd	114 gpd	138 gpd	164 gpd	176 gpd
85 °F	89 gpd	123 gpd	150 gpd	177 gpd	191 gpd
90 °F	97 gpd	133 gpd	162 gpd	192 gpd	207 gpd
95 °F	105 gpd	144 gpd	175 gpd	208 gpd	224 gpd

TQ172

Nanofiltration System

Compensated Inlet Pressure

Temperature	40 psi	50 psi	60 psi	70 psi	80 psi
40 °F	44 gpd	61 gpd	74 gpd	87 gpd	94 gpd
45 °F	50 gpd	69 gpd	84 gpd	99 gpd	107 gpd
50 °F	56 gpd	78 gpd	94 gpd	112 gpd	120 gpd
55 °F	64 gpd	88 gpd	106 gpd	126 gpd	136 gpd
60 °F	71 gpd	98 gpd	120 gpd	142 gpd	153 gpd
65 °F	80 gpd	110 gpd	134 gpd	159 gpd	171 gpd
70 °F	90 gpd	124 gpd	150 gpd	178 gpd	192 gpd
75 °F	100 gpd	138 gpd	168 gpd	199 gpd	214 gpd
80 °F	110 gpd	152 gpd	184 gpd	218 gpd	235 gpd
85 °F	119 gpd	164 gpd	200 gpd	237 gpd	255 gpd
90 °F	129 gpd	178 gpd	216 gpd	256 gpd	276 gpd
95 °F	140 gpd	192 gpd	234 gpd	277 gpd	298 gpd

TQ173

Reverse Osmosis System

Compensated Inlet Pressure

Temperature	40 psi	50 psi	60 psi	70 psi	80 psi
40 °F	50 gpd	68 gpd	83 gpd	98 gpd	106 gpd
45 °F	56 gpd	77 gpd	94 gpd	111 gpd	120 gpd
50 °F	63 gpd	87 gpd	106 gpd	126 gpd	135 gpd
55 °F	71 gpd	99 gpd	120 gpd	142 gpd	153 gpd
60 °F	80 gpd	111 gpd	134 gpd	159 gpd	172 gpd
65 °F	90 gpd	124 gpd	151 gpd	179 gpd	193 gpd
70 °F	101 gpd	139 gpd	169 gpd	200 gpd	216 gpd
75 °F	113 gpd	155 gpd	189 gpd	224 gpd	241 gpd
80 °F	124 gpd	171 gpd	207 gpd	245 gpd	264 gpd
85 °F	134 gpd	185 gpd	225 gpd	266 gpd	286 gpd
90 °F	145 gpd	200 gpd	243 gpd	288 gpd	310 gpd
95 °F	157 gpd	216 gpd	263 gpd	312 gpd	335 gpd

TQ173

Nanofiltration System

Compensated Inlet Pressure

Temperature	40 psi	50 psi	60 psi	70 psi	80 psi
40 °F	66 gpd	91 gpd	111 gpd	131 gpd	141 gpd
45 °F	75 gpd	103 gpd	125 gpd	149 gpd	160 gpd
50 °F	85 gpd	117 gpd	142 gpd	168 gpd	181 gpd
55 °F	95 gpd	131 gpd	159 gpd	189 gpd	204 gpd
60 °F	107 gpd	148 gpd	179 gpd	213 gpd	229 gpd
65 °F	120 gpd	166 gpd	201 gpd	238 gpd	257 gpd
70 °F	135 gpd	185 gpd	225 gpd	267 gpd	287 gpd
75 °F	150 gpd	207 gpd	252 gpd	298 gpd	321 gpd
80 °F	165 gpd	227 gpd	276 gpd	327 gpd	352 gpd
85 °F	179 gpd	247 gpd	299 gpd	355 gpd	382 gpd
90 °F	194 gpd	267 gpd	324 gpd	384 gpd	414 gpd
95 °F	209 gpd	289 gpd	350 gpd	415 gpd	447 gpd

Note: The above charts are best on using an atmospheric storage or QuickFlo™ tank

System Sizing TQ 174 / 176

In the application of the TQ Series cabinet systems, two important site variables must be taken into account:

Water Temperature
Inlet Water Quality (TDS)

TQ 174 Production Chart 75 psi feed pressure to atmospheric tank

		TDS				
Temperature °F		500	1000	1500	2000	2500
	45	189	169	151	133	116
	55	240	214	189	166	142
	65	300	267	234	203	174
	75	371	328	287	247	209
	85	445	391	340	291	245

Note: Production rates in gallons per day (GPD)

TQ 176 Production Chart 70 psi feed pressure to atmospheric tank

TDS						
Temperature °F	500	1000	1500	2000	2500	
	45	208	190	163	142	121
	55	264	233	204	176	149
	65	330	290	253	216	181
	75	407	356	308	262	217
	85	488	425	365	308	255

Note: Production rates in gallons per day (GPD)

TQ 174 Production Chart 75 psi feed pressure to a bladder tank

TDS	
Temperature °F	
	500
	1000
	1500
	2000
	2500
45	168
55	213
65	267
75	330
85	395

Note: Production rates in gallons per day (GPD)

TQ 176 Production Chart 70 psi feed pressure to a Bladder tank

Temperature °F	TDS					
	500	1000	1500	2000	2500	
	45	183	160	139	118	98
	55	232	202	173	146	120
	65	290	252	214	179	145
	75	358	309	261	216	174
	85	430	368	309	254	203

Note: Production rates in gallons per day (GPD)

EQUIPMENT SPECIFICATIONS

System Configuration

Depending on the inlet characteristics of your water, additional components may be required with your TQ Series System. The configuration of these accessories along with their functionality has been listed at the end of this section. Should you require further information regarding this equipment, please contact your local Kinetico Dealer.

Backwashing Filter

The TQ Series Systems require prefiltered water for adequate TSS (total suspended solids) removal. Kinetico offers a wide range of backwashing filters using a variety of medias. Depending on the types of solids in the water, the appropriate media is matched for your application. Kinetico's laboratory can test for the TSS content of feed water if it is not known to help determine the type of prefilter required. High levels of TSS can cause fouling of the TQ System membrane, thus reducing both the quality and quantity of the permeate water.



The maximum silt density index (SDI) for the influent water is 3.0. Operation above an SDI of 3.0 may damage membranes, pump or motor. At this point, the only remedy is to replace the damaged components.

Carbon Filter

A carbon filter is required to protect the TQ System's membrane from organic fouling or from chlorine degradation. Both these types of fouling can seriously damage the TQ System's thin film composite membrane(s). With chlorine degradation, the membrane is slowly damaged. This type of damage is irreversible.



Each TQ unit is equipped with a sediment prefilter cartridge. For applications requiring carbon pretreatment where the actual daily consumption volume is low (< 50 gpd), a carbon sediment prefilter can be used in its place. One should note that the maximum capacity of this cartridge is 1,500 gallons at 2 mg/l of free Cl_2 . Based on this capacity, cartridge replacement should be calculated.



The maximum influent level of chlorine to the TQ System is 0.05 mg/l. Prolonged exposure to excessive levels of chlorine will cause membranes to be destroyed. At this point, the only remedy is to replace the membranes.


Softener

For RO systems, a maximum inlet hardness of 4 gpg (68.4 mg/l as CaCO_3) is required. Above this level, scaling will occur within the RO's membrane(s). Calcium and magnesium are the two primary constituents leading to scale build up on the RO's membrane(s). To prevent this scaling, a softener can be used to remove calcium and magnesium from the water. A chemical descalant may be substituted for pre-softening the water in some applications. However, some chemical additives may result in a poorer quality of permeate water from the TQ RO.

For units with nanofiltration membranes, the maximum inlet hardness is 20 gpg. Nanofilter membranes are less sensitive to hardness fouling than their RO counterparts. A hard water source is preferred when specifying a nanofiltration unit, as the system's rejection rate for calcium and magnesium is much greater than it is for sodium ions.

TQ Series Membranes

The TQ Series uses membrane technology to reduce the level of total dissolved solids (TDS) in a feed stream. The system uses spiral wound membranes for production of permeate water. The permeate water from the system typically exhibits a 95% or better reduction of TDS from the feed water when using reverse osmosis style membranes. With nanofiltration membranes, this rejection is typically on the order of 70% TDS reduction. The reject water contains the concentrated minerals that have not been permitted to pass through the membrane. The TQ system also features EverClean[®] Rinse which extends the operating life of the system's membranes by flushing the entire feed side of the membrane with high quality permeate water before its idling mode.



Storage Tanks

Three different types of storage vessels are possible with the TQ Series.

Pressure Storage Tank

These accumulator-type vessels come equipped with a valve, tee fitting and 1/2" tubing fitting. The tanks are precharged to 7 psi, allowing for the permeate water to remain pressurized during operation.

QuickFlo[®] Storage Tank

Kinetico specially manufactures the QuickFlo[®] tank for operation with our membrane systems. The tank's special design allows for the unit to be vented to atmosphere while water is being processed to the tank. This configuration provides no backpressure, and therefore maximizes the output production of the membrane system. When water is required from the tank, an internal spool valve shifts, and the pressure from the tap source is now used to drive the water from the tank. During delivery, this configuration will provide a consistent flow and pressure.

Atmospheric Storage Tank

These tanks offer the greatest storage volume. For applications that require a large volume of water, during a very small period of time, an atmospheric tank offers the best cost value.

Pressurized Storage Tanks

Model Number	Rated Size	Diameter	Height	Weight	Capacity to low level
4461	10 gal. (39 l)	16" (41 cm)	24" (61 cm)	24 lbs. (11 Kg)	2.5 gal. (9.5 l)
7481	20 gal. (78 l)	16" (41 cm)	33" (84 cm)	26 lbs. (12 kg)	4.8 gal. (18.2 l)
7482	40 gal. (156 l)	16" (41 cm)	58" (147 cm)	43 lbs. (20 Kg)	9.7 gal. (36.7 l)
7483	80 gal. (302 l)	24" (61 cm)	57" (145 cm)	65 lbs. (30 Kg)	16.4 gal. (62 l)

* Empty Weight

QuickFlo Tanks

Model Number	Rated Size	Diameter	Height	Weight*	Capacity to low level
9496	3 gal. (11.3 l)	8" (20.3 cm)	17" (43.2 cm)	2.5 lbs. (1 Kg)	3 gal. (11.3 l)

Atmospheric Tanks


Model Number	Rated Size	Diameter	Height	Weight*	Capacity to low level
7495	300 gal. (1,136 l)	35" (88.9 cm)	80" (203.2 cm)	85 lbs. (39 Kg)	225 gal. (852 l)
7496	550 gal. (2,082 l)	48" (121.9 cm)	83" (210.8 cm)	120 lbs. (54 Kg)	413 gal. (2,414 l)
7497	850 gal. (3,218 l)	48" (121.9 cm)	120" (304.8 cm)	190 lbs. (86 kg)	638 gal. (2,840 l)
7498	1,000 gal. (3,786 l)	64" (162.6 cm)	84" (213.4 cm)	205 lbs. (93 Kg)	750 gal. (2840 l)

The chart below shows the storage capacity for pressurized storage tanks at various precharges.

To determine this volume:

1) Find the point on the horizontal axis at the bottom of the graph that represents the total pressure (air plus water) in the tank. Move vertically to the air pre-charge line found in step 1.

2) Move horizontally to the left axis and read the percent of "maximum total volume" in the tank under the above conditions. Multiply this percentage by the maximum total water volume to determine the volume of water in the tank.



Repressurizer Pump

If an atmospheric-type holding tank is used, then the water must be repressurized for use throughout the facility.

Atmospheric Storage Tank Accessories

Part Number	Description
7527	Level Control Assembly Atmospheric Tank
9837	Bulkhead Kit, CRO
10208	Repressurizer, TS 115 Volt
10209	Repressurizer, TS 230 Volt
8736*	3 Gallon EverClean Rinse Accumulator

* If an atmospheric tank is used with the level control, an accumulator tank must be added to shut off the unit properly.

The following fittings should be added:
 #8939 Conn, Tube 3/8T x 1/2 Stem
 #8308 Tee, 1/2 Union
 #9336 Valve, Ball 3/8 Stem

Filter Accessories

Part Number	Description
9046	Filter Asy, Single 20" Housing w/Bracket
9047	Filter Asy, Double 20" Housing w/Bracket
7474	Cartridge, Carbon Matrix for 20" Housing
367	Cartridge, Prefilter 5 Micron for 20" Housing
7477	Cartridge, Sediment/Declor 5 Micron for 20" Housing

Miscellaneous

Part Number	Description
3814	Wrench, Filter Sump

Operating Specifications

General operating parameters for the TQ product line have been listed in the table below. These specifications have been provided to express the required conditions for the operation of this system. If there are other parameters that you may be concerned about, please contact your local Kinetico Dealer for further operating or performance data.



Exceeding the conditions in the table below may inhibit performance or could cause the system to be permanently damaged.


To assure that these factors are being met, a yearly water analysis is recommended to keep track of your influent water quality. This can be a beneficial tool in recognizing changes in your inlet water supply. If the inlet supply does change, please contact your area Kinetico Dealer. Modifications to the system or additional equipment may be required to maintain peak operation efficiency of your system.

Model #	TQ 172	TQ 173	TQ 172n	TQ 173n	TQ 174	TQ 176
Inlet Filter	Sediment Cartridge				None	
Membrane Performance	Low Energy RO or Nanofiltration				Low Energy	
Membrane Type	Thin Film Composite					
Membrane Dimensions	1.75" x 11"					
Number of Membranes	2	3	2	3	4	6
Square Footage of each Membrane	1.6 Ft ²					
Array Configuration	Parallel					
Drain Control	Capillary Tube					
Permeate Flush, per membrane	5 oz reservoir					
System Shut-Off Control	Internal Pressure					
System Controller	Hydraulic					
Power	None				120/60 or 230/50	
Inlet Connection	3/8" Tubing					
Permeate Connection	3/8" Tubing					
Drain Connection	3/8" Tubing					
EverClean Rinse Connection	Internal/Automatic					
Pressure	40 - 100 psi				20 - 80 psi	
Temperature	40 - 95 °F					
pH	4-11 SU					
Chlorine	< 0.05 mg/l as Cl ₂					
Hardness (Max.)	4 gpg	4 gpg	20 gpg	20 gpg	4 gpg	4 gpg
Silica (Max.)	< 10 mg/l as SiO ₂					
Iron (Max.)	< 0.1 mg/l as Fe					
Total Dissolved Solids (Max.)	< 2,500 mg/l as NaCl					
Inlet Flow Rate	0.2 gpm	0.3 gpm	0.2 gpm	0.42 gpm	.42 gpm	.62 gpm
Permeate Flow Rate	0.1 gpm	0.15 gpm	0.1 gpm	0.21 gpm	.21 gpm	.31 gpm
Reject Flow Rate	0.1 gpm	0.1 gpm	0.1 gpm	0.21 gpm	.21 gpm	.31 gpm
Daily Production*	150 gpd	225 gpd	200 gpd	300 gpd	300 gpd	450 gpd
Operating Pressure Range	40 - 100 psi				20 - 80 psi	
Normal Operating Pressure	70 psi				70 - 90 psi	
Rejection Rate - NaCl	> 95%	> 95%	> 50%	>50 %	> 95%	> 95%
Rejection Rate - Ca ₂ SO ₄	> 99%	> 99%	> 85%	>85 %	> 99%	> 99%
Recovery Ratio Atmospheric	50%	50%	50%	50%	50%	50%
EverClean Rinse Volume	10 oz.	15 oz.	10 oz.	15 oz.	20 oz.	30 oz.
Width	18"				8.5"	
Depth	6"				18.75	
Height	18"				20.5	
Weight	10 lbs.	13 lbs.	10 lbs.	13 lbs.	50 lbs.	58 lbs.
Part #	10162	10163	10166	10167	11585	11560

* Based on 77 degree F water, 500 TDS feed, Permeate to Atmospheric Tank, 70psi operating pressure

Component Functionality TQ 172 - 173


The TQ System is comprised of various components. A brief description has been provided for each of these major components. The illustration helps depict the physical location of these components on the TS system, while the flow schematic shows the flow path through the system.



Inlet The inlet to the system is located on the left side of the TQ System. This connection is designed for 3/8" O.D. tubing.



Do not use smaller than 3/8" tubing on the inlet connection.




Bracket

An aluminum anodized bracket is used to support the multi-membrane structure. The frame allows for quick and convenient installation in a wall-mounted configuration.

Pre-filter Cartridge

A sediment prefilter is included standard with each TQ system. If the daily water usage is low (<50 gpd), then a carbon prefilter could possibly be substituted for the sediment filter. Careful attention must be made to assure timely replacement of the carbon prefilter, due to its capacity for chlorine removal.




System Cover

A decorative cover is used to shield the feed, permeate and drain plumbing manifolds. This cover can be removed should maintenance be required on any of the internal components.

Membrane Housing/Membrane


Three membrane housings are used on the TQ Series. With the 172 configuration, only two of the housings include the membranes. This allows for a quick upgrade to a third membrane should the customer require the additional capacity. Membranes used are thin film composite. The operating efficiency of this membrane is affected by operating pressure, inlet water quality, water temperature and storage tank choice.



Permeate Manifold The permeate manifold (Blue) uses 3/8" tubing to connect water from the permeate to a common bulkhead.


Inlet Manifold The inlet manifold (Black) uses 3/8" tubing to connect water from the outlet of the filter cartridge to each membrane housing.

Drain Manifold The drain manifold (Green) uses 3/8" tubing to connect water from the drain outlet of the membrane housings to the bulkhead.



Permeate Outlet The permeate outlet uses 3/8" tubing connection and is located at the back of the unit.


Drain Outlet The drain outlet uses 3/8" tubing connection and is located at the front of the unit.




EverClean® Rinse Each housing internally contains a permeate reservoir. During shut down modes, this water is used to flush the membranes, keeping them in optimal condition.


Component Functionality TQ 174 - 176

The TQ System is comprised of various components. A brief description has been provided for each of these major components. The illustration helps depict the physical location of these components on the TS system, while the flow schematic shows the flow path through the system.






Membrane Housing/Membrane The cabinet houses four or six membrane housings. Four housings are used on the 174 and six on the 176. This allows a 174 to be upgraded to a 176 should the customer require the additional capacity. Membranes used are thin film composite. The operating efficiency of this membrane is affected by operating pressure, inlet water quality, water temperature and storage tank choice.




Drain Manifold The drain manifold (Green) uses 3/8" tubing to connect water from the drain outlet of the membrane housings to the bulkhead.

Permeate Manifold The permeate manifold (Blue) uses 3/8" tubing to connect water from the permeate to a common bulkhead.


Inlet Manifold The inlet manifold (Black) uses 3/8" tubing to connect water from the outlet of the filter cartridge to each membrane housing.



System Booster Pump The pump is located inside the cabinet on the bracket. It is used to boost the system pressure on the feed to the membranes.



Pressure Switch The inlet pressure switch is used to start the booster pump. It is preset and does not need to be adjusted.



EverClean® Rinse Each housing internally contains a permeate reservoir. During shut down modes, this water is used to flush the membranes, keeping them in optimal condition.

INSTALLATION

Getting Started

The following procedures have been developed to assist during the installation of your TQ System.



The installation of this TQ Membrane System should be performed by a qualified service person with an understanding of local and regional codes that may affect the installation requirements.

Pre-installation Review

Should there be any visible shipping damage to the TQ System, please contact your freight company for coverage information. Before beginning the installation of the TQ System, confirm system configuration to be installed, and components that have been ordered. Please review TQ System specification sheet that includes required components.

Review of the customer's facility is also recommended, especially critical operating data that could effect the operation of the system:



Water Pressure

Water pressure to the TQ System will effect maximum flow permitted by the system. The TQ 172 – 173 systems will not operate if the inlet pressure fluctuates below a dynamic pressure of 40 psi. This minimum pressure must be maintained to the system at all times. Should the pressure fluctuate below this level, a booster pump may be required. The TQ 174 – 176 require 20 psi. inlet pressure.



Temperature

Ambient temperature must be maintained above 32°F (0°C). Freezing temperatures will cause breakage of equipment and void all warranties.



Water Temperature

Inlet water temperature must be maintained between 40°F (4.4 °C) and 95°F (35 °C) to prevent damage to the system's membranes.



System Location

The unit must be installed indoors. Failure to comply with this requirement can cause significant damage to the system and will create a safety concern.

TS RO Installation



Tools and Installation Materials

Since the TQ System process high quality water, plumbing runs on the process, purge and drain outlets should all be completed with High Density P.P or P.E. tubing. Copper and galvanized pipe will be chemically attacked by the permeate water.

Teflon™ Tape
Fitting Sealant
3/8" Tubing Wall Mount

Plastic Tube Cutter
Phillips head screwdriver (medium and small)
Additional 316 SS pressure gauges

Unpacking

Remove the TQ System and components from the shipping carton and check for damage.
When handling the wall unit, pick it up by the metal frame.
Lift the cabinet unit by lifting the cabinet. Lifting the system by any other component may damage the unit.

Check all tube fitting connections and make sure they are tight.


Cover

Install the cover to the top of the unit.


System Hook-ups



1. The wall mount system should be securely mounted to the wall. Two 1/4" diameter mounting holes, 8" on center, are provided on the back of the system. The cabinet unit sits on the floor. Rolling casters can be added to the bottom as an option.
2. Connect the water supply to the feed port on the left side of the wall mount unit (when facing the unit). One 3/8" O.D. tubing will be needed for this connection. The cabinet unit feed port is located on the back side of the cabinet. One 3/8" O.D. tubing will be needed for this connection. Be sure to install a shutoff valve on the inlet supply.
3. To avoid excessive pressure drop to the system, be sure the inlet tubing run is kept to a minimum. (Recommended less than 10'.) If a longer plumbing run is required, use a large size plumbing, then reduce the size when the line gets to the TQ System.
4. Connect the permeate outlet to the storage tank. This connection is made with 3/8" tubing. A relief valve may be required between this connection.
5. Connect the drain port to a suitable drain outlet. Be sure to follow applicable plumbing codes when making the drain connection. Use 3/8" tubing for the connection.
6. Open the feed water supply valve slowly. Check the system for leaks.
7. Disconnect the permeate line from the storage vessel and temporarily connect to a drain or five gallon bucket so the preservative can be flushed out of the system.
8. Plug the cabinet unit into a standard 115 / 60hz or 230 / 50hz electrical outlet. Use the power cord supplied with the unit.



Tubing Connections



Mounting Holes

OPERATION AND MAINTENANCE

Normal Operating Procedures

During the normal operation of the TQ System, a few items are required to be checked daily. Routine upkeep with these items will maintain the operation of the TQ to its highest standards.

Daily Start-up/Shutdown

The equipment will run in an automatic mode, shutting itself off when the storage tank is full. Each time the unit shuts down, the EverClean® Rinse is set to flush each membrane with permeate water.

Daily Log

On the back page of this manual, a daily log has been provided. Photocopy this template and use it for recording the system's daily performance. By recording various system characteristics each day, this will help in any future troubleshooting of the equipment. It is also necessary to keep a daily performance log to show changing performance characteristics of the TQ System. These changes may be the result of membrane fouling. With accurate logs kept on performance, timely cleaning of the membranes will insure maximum membrane life.

The parameters included on the daily log sheet are:

- Date
- Feed Pressure (if an extra gauge is added)
- Permeate Flow Rate
- Water Temperature
- Water Quality
- Comments

Routine Maintenance

Filter Maintenance (Optional)

The inlet filter should be change at least twice per year. If the filter becomes blocked, the dynamic pressure to the membranes will be reduced, and the system's performance will be diminished. The system will not operate properly if the inlet pressure drops below 40 psi for the wall-mount unit (20 psi for cabinet unit). The cabinet unit does not have a prefilter standard, so one must be added.

Check the daily log for changes in the inlet pressure if an optional gauge is added. One can predict the life of the filter before its use has become over-exhausted by using the daily log as a preventative maintenance tool.

If a carbon cartridge is used with the system, then cartridge replacement will become more frequent. The capacity of the carbon cartridge is 1500 gallons, based on 2 mg/l of free Cl_2 . Cartridge replacement must occur before exhaustion, or the membrane will be damaged.

System Commissioning (Initial Start-up)

The start-up procedures for the equipment should be followed if:

- It is the first time the unit is being put into operation.
- The equipment has been moved.

-The unit has been shut down for an extended period of time (a few weeks).

After completing these start-up procedures, the normal operating procedure should be followed.

1. Make sure the unit has been properly installed by reviewing the installation section.
2. Temporarily connect the permeate line to a drain or a bucket.



IMPORTANT

The membrane sanitizing solution must be properly rinsed from the membrane during installation. DO NOT drink the water from the system during this rinsing procedure.

3. Open the feed water valve slowly to pressurize the system. (For TQ 174 & TQ 176 plug unit into electrical connection.)
4. Check the unit for leaks.
5. Tighten any connections exhibiting leaks.
6. Do not exceed 100 psi on system. Excessive pressure will damage the system.
7. After 1/2 hour of operation, the membranes should be adequately flushed of any preservatives.
8. Shut the system down by closing the inlet water valve.
9. Connect the permeate line to the storage tank.
10. Restart the system by opening the inlet water valve.
11. At this time, permeate water should begin filling the storage tank.

Sanitization Procedure for Standard storage tank

- a. Shut off the inlet water supply to the TQ system.
- b. Drain any remaining water from the storage tank.
- c. Connect a sanitization cartridge in the line feeding the storage tank. The sanitization cartridge is a separate device that must be plumbed in and removed after the sanitization is complete. Connect a line from the inlet water supply to the inlet of the sanitation cartridge. Connect a line from the outlet of the sanitation cartridge to the storage tank.
- d. Fill the sanitization cartridge 3/4 full with clean water. Add (2 ml) of regular, unscented household bleach (5-1/4% sodium hypochlorite) to the center of the cartridge for every gallon the storage tank holds (example a 20 gallon tank would have 40ml added). (If a sanitization cartridge is not available, household bleach may be added directly into the tubing feeding the storage tank.)
- e. Be sure the storage tank valve is open and the outlet valve is closed. Slowly open the cold water supply valve and allow chlorinated water to fill the storage tank (fill time may vary based on the size of the storage tank).
- f. Close the cold water supply valve and the storage tank valve. Open the outlet valve to depressurize the system, then close the valve. Remove the sanitization cartridge and discard the water it contains. *Be*

prepared to catch accidental spills from this cartridge. Install the protective cap back on the sanitization cartridge, and save it for future use.

- g. Reconnect the tubing to the storage tank.
- h. Open cold water supply valve and open ball valve on the storage tank. This will allow the system to fill the storage tank with water. After the storage tank has filled, discard the water in the tank. When the tank refills for the second time the system is ready for use.


Sanitization Procedure when using QuickFlo Storage Tank

The following steps outline the sanitizing and/or pre-filling procedure of a QuickFlo® tank prior to installation.

NOTE: *It is recommended that this procedure be performed off site.*

Requirements:

- Two pressurized feed lines.
- One line that can introduce chlorinated water to the product side of the tank.



Membrane Sanitization

- a. Shut off the inlet water supply to the TQ system.
- b. Drain any remaining water from the storage tank.
- c. Remove the prefilter cartridge. Be prepared to catch accidental water spills when removing the cartridge.
- d. Use a sanitization cartridge to sanitize the membrane. Add 1 cup of clean water with 3 teaspoons of Iron Out or sodium meta bisulfite to the center of the sanitization cartridge. It may be best to premix the solution first to get an adequate dilution before adding it to the sanitization cartridge. A small, plastic, household funnel or the dropper provided in Kinetico's sanitization kit may aid in adding solution to the cartridge. After adding solution to the cartridge, install cartridge to the prefilter head.
- e. Disconnect the tubing from the storage tank ball valve, and put the tubing end into a bucket or drain. Open the cold water supply valve, and allow the product water to discharge from the tubing into the bucket or drain for 15 to 20 minutes. Close the cold water supply valve, and reconnect the tubing to the storage tank ball valve. If the tubing end is scarred or scratched, cut away the damaged end before connecting it to the tank.
- f. Remove the sanitization prefilter cartridge, and replace it with a new prefilter cartridge.
- g. Open ball valve on the tank and the cold water feed line. Allow the system to fill the storage tank for several hours. Discard the water in the tank after this time. When tank refills, the system is ready to use.

Troubleshooting

Poor Quality

Inlet TDS too high

Check inlet TDS. TQ RO is designed to operate with a ~ 98% rejection. The TQ Nano is designed to operate with a ~ 85% rejection.

Permeate flush not operating

Cycle system through permeate flush by allowing the storage tank to fill and go through a normal flush cycle. Check flush time and volume to reject during flush. Check reject quality at the end of the flush; it should be RO quality.

System not operating within specifications

Confirm system operating parameters see Operating Specifications table. The system should run at provided permeate and reject flow rates. Also check the system pressure.

Brine seal leak

Check permeate conductivity for each housing. If one or some show poor readings, service the membranes.

Chlorine/Oxidizer damage to membranes

Check inlet chlorine or ozone levels. Residual less than 0.05 mg/l is required to prevent thin film composite membrane deterioration. Check downstream of the prefilter.

Pressure too low (<40psi)

Check and add booster pump if pressure is too low.

Membrane plugged or fouled

Check, clean or replace.

Insufficient reject flow rate

See “No reject water.”

Membrane expended

Replace membrane.

System Not Consistently Running

Low permeate flow

Water temperature is low. Plugged prefilter or low feed psi.

Membranes are fouled.

Membranes fouled


Check system log for history. If consistent declining production is found, clean membranes. Consult your Kinetico dealer for appropriate cleaning procedures and chemicals.

Confirm proper system operating parameters.

No accumulator tank	A stable pressure signal is required for the unit to shut off properly. In some cases, only using tubing to connect the TQ unit to an atmospheric storage tank may not provide enough volume in the line to hold the pressure signal. The addition of an accumulator tank (less than 1 gallon) will resolve this issue.
Accumulator tank lost air precharge	Pump up tank air pressure to 7 psi. Check for cause of failure.
Prefilter fouled	Replace.
Frequent Membrane Cleaning Required	
Ineffective cleaning solution	Silica treatment requires caustic cleaners that are heated to 90°F for maximum effectiveness. Hardness contamination is cleaned with acid chemistries.
Improper cleaning procedures	Temperature, flow rate, time and chemistry must all be matched to the specific foulant being cleaned. Improper procedure will result in poor cleaning cycles.
Damaged membranes	Replace membranes.
Poor Production Volume	
System not operating within specifications	Confirm system operating parameters. See Operating Specifications table. The system should run at provided permeate, and reject flow rates. Also check the system pressure.
Cold Temperature	Inlet temperature is less than 77°F. Cold water will have a lower production rate. See sizing charts for different temperatures.
Fouled membranes	Check permeate quality with a hand-held meter. Also check permeate flow rate.
Inlet quality changes	Analyze the TQ Systems' feed for chlorine, hardness, temperature and SDI.
Tank precharge pressure too high	Relieve to 7 psi. Check pressure while system is empty.
Tank lost air precharge	Pump up air precharge to 7 psi and check for cause of failure. Note: tank must be empty to add more precharge.
Prefilter cartridge plugged	Replace cartridge.
Insufficient reject flow rate	See "No reject water."
Membrane fouled	Determine and correct cause; replace membrane. A new feed analysis may be required.
Insufficient storage capacity	Check charts in Options Section for draw down capacity.

No reject water	
Plugged drain line or outlet	Check and clean.
Low flow rate at point of use	
Low water production	See “No water or not enough water.”
Tank lost air precharge	Pump up air precharge to 7 psi. and check for cause of failure.
Tank diaphragm failed	Replace as necessary.
Pump pressure low	Check and adjust.
Bad tasting water	
Increase in product TDS	See “High product water TDS.”
Postfilter cartridges exhausted	Replace filter cartridges.
Tank contaminated	Re-sanitize tank/system, and replace post filter cartridge.
Unit cycles on/off intermittently	
Air precharge too low	Adjust to 7 psi while the tank is empty.







Parts TQ 174/176

Item #	Part #	Title	Qty
1	11561	Cabinet, TQ176	1
2	11574	Bracket, TQ176	1
3	8563	Collet, 1/4", Plastic	18
4	10139	Module Tube 90 elbow	18
5	11575	Pump, 24 VDC	1
6	10135	Tee, Union, 3/8" T x 1/4" T, PP	15
7	10126	3/8" Stem x 3/8" Tube, Elbow	5
8	10138	Bulkhead 3/8" T X 3/8" Parker	3
9	11568	Permeate Tube, 0375, 30", BLU	1
10	11565	Inlet Tube, 0375, 27" L, BLK	1
11	10886	TQ Low Pressure Switch	1
12	11567	Drain Tube, 3/8"x30" L, GRN	1
13	11564	U-Tube/Permeate, 0375 x 9" L, Blue	1
14	10136	Elbow, .25" T x .375" T, Parker	3
15	11562	9" Tube, .375", BLK	1
16	11566	6" Tube, 3/8", BLK, Inlet 2	1
17	11562	9" Tube, .375", BLK	1
18	11690	Cover, TQ176 - Painted	1
19	11526	Caster Wheel Kit	4
20	11571	Washer, Flat, M6	4
21	11522	M6x14mm L, Socket Cap Head Screw	4
22	71495	Washer, Flat, 3/8", Zinc Plated	1
23	11570	Connector, 0125FNPT x 025T, PP4FC2	1
24	10127	Elbow Male, 1/4" T x 1/4" NPT, PP4ME4	1
25	11579	Foam, TQ176	1
26	11573	Washer, Flat M5	4
27	11572	M5x35mm L, Socket Cap Head Screw	4
28	10142	3.5" Tube, 3/8", BLK	4
29	10144	3.5" Tube, 3/8", Blue	4
30	10143	3.5" Tube, 3/8", GRN	4
31	11569	16" Tube, 1/4", Black - Pressure Switch	1
32	11525	Logo Plate, SS, Kinetico, 5"	1
33	11582	14-16 Terminal, Female, Insulated	2
34	10146	Prd Dcl - Labels / Logo TQ	1
35	10150	Plug, 3/8" PP	3
36	11580	DC Power Jack Cable Assy	1
37	10500	Module Asy-Plus TF 75	6
38	9386A	Prd Dcl-Labels / Serial Number Blank	1
39	11576	24VDC Power Supply	1
40	11577	Power Cord - US	1

See drawings following pages





PARTS

Part #	Description	TQ Units					
		172	172n	173	173n	174	176
10134	Bracket, TQ 172/173	X	X	X	X	n/a	n/a
11574	Bracket, TQ 174/176	n/a	n/a	n/a	n/a	X	X
10148	Cover, TQ 172/173	X	X	X	X	n/a	n/a
11561	Cabinet, TQ 174/176 Black	n/a	n/a	n/a	n/a	X	X
11578	Cover, TQ 174/176	n/a	n/a	n/a	n/a	X	X
10500	Module Asy-Plus TF75	X	n/a	X	n/a	X	X
10501	Membrane, TF75 GPD	X	n/a	X	n/a	X	X
10159	Module Asy-Nano	n/a	X	n/a	X	n/a	n/a
10121	Membrane, Nano	n/a	X	n/a	X	n/a	n/a
10141	Prefilter Head, 1/4fnptx1/4fnpt	X	X	X	X	n/a	n/a
10126	Elbow 3/8T x 3/8T	X	X	X	X	X	X
10135	Tee, Union 3/8 TR x 1/4 TB	X	X	X	X	X	X
10125	Conn 1/4MNPT x 3/8 T	X	X	X	X	X	X
10138	Bulkhead Union 3/8T	X	X	X	X	X	X
10139	Elbow Tube Custom	X	X	X	X	X	X
10142	Tubing, 3/8 x 3 1/2 lg Blk	X	X	X	X	X	X
10143	Tubing, 3/8 x 3 1/2 lg Grn	X	X	X	X	X	X
10144	Tubing, 3/8 x 3 1/2 lg Blu	X	X	X	X	X	X
10152B	Manual/Install TQ	X	X	X	X	X	X
10886	Switch Low PSI TQ 174/176	n/a	n/a	n/a	n/a	X	X
11575	Pump, 24 VDC	n/a	n/a	n/a	n/a	X	X
11577	Cord, Power US 120/60	n/a	n/a	n/a	n/a	X	X
11587	Cord, Power- European	n/a	n/a	n/a	n/a	X	X
11642	Cord, Power- UK	n/a	n/a	n/a	n/a	X	X
11643	Cord, Power- Australia	n/a	n/a	n/a	n/a	X	X
11644	Cord, Power- Denmark	n/a	n/a	n/a	n/a	X	X
11521	Wheel, Caster	n/a	n/a	n/a	n/a	X	X
11708	Kit, Cabinet Feet, Rubber					X	X
11580	Cable Assembly 24VDC	n/a	n/a	n/a	n/a	X	X
11525	Logo Plate Staninless Steel	n/a	n/a	n/a	n/a	X	X

SYSTEM LOG

Comments																				
QUALITY	Permeate																			
	Feed																			
Temperature																				
Permeate Flow																				
Pressure																				
Date																				

TQ REVERSE OSMOSIS SERIES

Manual part number: 10152B

© Kinetico Incorporated, August 2004